

STANDARD DOORS

Maintenance Requirements and User Information



Specialists in composite doors



Your New Door – Locking Instructions

Split Spindle Lever/Lever Handles

To unlock from the outside


Unlocking is achieved by turning the key and depressing the external lever handle to retract the central deadbolt and locking hooks, a further turn of the key will retract the centre latch and allow entry to the property.

To unlock from the inside

Unlocking is achieved by turning the thumbturn or key and depressing the internal lever handle to retract all locking mechanisms and allow exit from the property.

To lock from the inside or outside

Locking is achieved by lifting the lever handle to engage the locking hooks, and then turning the thumbturn or key to deadlock the mechanism.



Solid Spindle Lever/Lever Handles

To unlock from the outside


Unlocking is achieved by turning the key and depressing the external lever handle to retract all locking mechanisms and allow entry to the property.

To unlock from the inside

Unlocking is achieved by turning the thumbturn or key and depressing the internal lever handle to retract all locking mechanisms and allow exit from the property.

To lock from the inside or outside

Locking is achieved by lifting the lever handle to engage the locking hooks, and then turning the thumbturn or key to deadlock the mechanism.



Please ensure that whenever the door is shut, the multipoint locking system is fully engaged into the frame by lifting the handle up. This will help to eliminate thermal movement in the door leaf. Failure to do this could invalidate your guarantee


Your New Door – Cleaning & Maintenance

Cleaning & Maintenance Guidelines

Your door is designed to be low-maintenance. All that is required, is on a regular basis (3 months) simply wipe the outside and inside faces of the door and the plastic frame with a soft damp cloth and warm soapy water using a mild detergent.

Check the seals around the glass and the door for wear and tear on a regular basis, once every three months or so.

The drain holes in the threshold should be inspected on a regular basis and kept clear of debris build up.



Do **NOT** use abrasive cleansers, metal polishes or solvent based cleansers on the door or its fittings.



Do **NOT** use oil on the hinges, handles or locking system. If lubrication is needed you should use a light machine oil (such as 3-in-1), petroleum jelly or lithium grease.



Do **NOT** paint the door.



Warranty Information

Do **NOT** fit anything to this doorset that requires drilling into or through the door leaf or frame as this will invalidate the warranty.





Permadoor Head Office | Upton-upon-Severn | Worcestershire | WR8 0RX

Tel: 01684 595200 | Fax: 01684 594283 | Email : info@permadoor.co.uk

www.permadoor.co.uk